

Aircraft	Compass Deviation											18-Aug-21	
	N	30	60	E	120	150	S	210	240	W	300	330	
N138UD	359	029	059	089	119	149	180	210	240	270	300	330	Radio ON
N139UD	360	030	059	089	119	149	179	209	240	270	300	330	Radio ON
N140UD	360	030	060	090	121	151	180	211	241	270	302	331	Radio ON
N142UD	360	030	060	089	120	150	180	210	240	270	300	331	Radio ON
N472D	360	030	060	091	122	152	182	212	241	270	301	330	Radio ON
N561D	360	031	061	091	122	153	182	211	241	270	300	330	Radio ON
N597D	360	030	060	092	122	153	182	211	241	270	301	330	Radio ON
N740D	360	030	060	092	122	152	181	211	240	270	299	329	Radio ON
N915D	360	030	060	090	121	151	182	211	240	270	300	330	Radio ON
N44UD	360	030	060	090	121	151	181	211	240	270	300	330	Radio ON
N45UD	360	030	060	092	122	153	182	212	242	270	300	330	Radio ON
N51UD	360	030	061	092	124	154	182	211	241	270	300	330	Radio ON
N57UD	360	031	061	089	120	150	180	208	239	270	300	330	Radio ON
N63UD	360	030	061	091	121	151	182	211	240	270	300	330	Radio ON
N76UD	360	030	060	090	120	151	180	210	240	270	300	330	Radio ON
N820D	359	031	062	092	121	151	180	209	239	270	301	329	Radio ON
N823D	360	029	059	089	119	150	180	210	241	270	301	330	Radio ON
N834D	360	030	061	091	121	151	181	210	240	270	300	330	Radio ON
N859D	360	030	060	092	122	152	180	210	240	270	300	330	Radio ON
N865D	360	030	060	090	120	150	180	210	240	270	300	330	Radio ON
N567SP	360	030	060	091	120	150	180	210	240	270	300	330	Radio ON
N899JR	360	030	060	090	120	150	180	210	240	270	300	330	Radio ON
N876MG	360	029	059	088	118	148	179	209	240	270	300	330	Radio ON
N101TF	360	030	059	089	120	150	180	210	241	270	300	330	Radio ON
N4437S	360	028	059	091	122	152	181	211	242	272	303	332	
N4437W	360	029	060	90	120	150	180	210	240	270	300	330	
N4438D	360	032	060	092	125	155	184	215	245	274	305	332	
N4438T	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	
N4438U	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	
	N	45		90	135		S	225		W	315		
N372PA	354	037		085	133		174	217		265	314		
N365PA	355	040		085	135		174	220		263	311		
N797NA	355	040		084	130		175	225		268	315		
N8535X	355	038		084	132		174	217		265	314		
N456PA	356	042		082	130		175	226		265	315		

Location: On Aircraft Maintenance Managers computer C:\Local User Documents\MAINTENANCE\Aircraft\Compass DEV 2021-08-18.xls

